

FUELTREAT

FUELTREAT USER APPLICATION GUIDE

User/Application	Surefire	Purge-EF	BC-250	Ecoshot 50ML *	FT-400	Brake and Contact Cleaner	Contact cleaner	Intake cleaner	Sureburn	BreakClear	Microb Monitor2 Test Kit
Vehicles											
City car / Minicompact Vehicles (1,000-2,500 cc)	√	√				√	√	√			
Sedan / Crossover MPV Vehicles (1,500-2,500 cc)	√	√				√	√	√			
SUVs / off-road Vehicles (2,000-3,200 cc)	√	√	√			√	√	√			
Pickup truck / Van Vehicles (2,000-3,200 cc)	√	√	√			√	√	√			
Truck / Construction Vehicles	√	√	√			√	√	√			
Scooters (50-100 cc)				√		√	√	√			
Motorcycles (125-250 cc)				√		√	√	√			
Big Motorcycles (more than 250 cc)				√		√	√	√			
Industrial											
Tank farm			√		√						√
Petroleum and petrochemical processing										√	√
Waste water treatment plants										√	√
Mining	√		√		√	√	√		√		
Co-generation systems									√	√	
Power Generator	√		√			√	√				
Marine											
Cruising Yachts	√		√			√	√	√			
Commercial Offshore Vessels	√		√		√	√	√	√			
Research Vessels	√		√		√	√	√	√			
Heavy Equipment											
Agricultural machinery	√	√	√			√	√	√	√		
Industrial machinery	√	√	√			√	√	√	√		

*Ecoshot 50ML

Scooters (50-100 cc- use 25ml / every 10 tank refills)

Motorcycles (125-250 cc- use 25ml// every 10 tank refills)

Big Motorcycles (more than 250 cc- use 50ml / every 10 tank refills)